

Global Attach Leader to Annotation

2662 GstarCAD MY /KW November 15, 2021 [Workflow](#) 0 928

Globally attaches leaders line to mtext, tolerance, or block reference objects

Menu : Express>Dimension>Global Attach Leader to Annotation

Command Entry : QLATTACHSET


Select objects: Select one or multiple leader lines and annotation objects

Usage Example:

Select leader line(s), and mtext objects to attach.

Select objects: Select one or multiple leader lines and annotation objects, the command line prompts: Number of unlocked leaders = 2, Number with annotation detached = 2


Leader with detached mtext object:



Leader attached to mtext object:



ATTACH LEADERS TO MTEXT OR
TOLERANCE OBJECT



ATTACH LEADERS TO BLOCK
REFERENCE OBJECT

Online URL:

<https://www.gstarcad.com.my/knowledge/article/global-attach-leader-to-annotation-2662.html>