

Move/Copy/Rotate

2674 GstarCAD MY /KW November 18, 2021 [Workflow](#) 0 1040

[Move](#) , [copy](#) , [rotate](#) , and [scale](#) object(s) with a single command.


Menu : Express tools>Modify>Move/Copy/Rotate


Command Entry : MOCORO

Command line prompts as follows:


Select objects: Select object(s) and press Enter

Base point: Specify a base point





[Move/Copy/Rotate/Scale/Base/Undo]<eXit>: Once an option is specified



Options

Move: Move object(s).

Copy: Make multiple copies of object(s).

Rotate: Rotate object(s).

Scale: Dynamically scale object(s).

Base: Specifies a base point for object(s) to be moved, copied, scaled or rotated.

Online URL: <https://www.gstarcad.com.my/knowledge/article/move-copy-rotate-2674.html>