

Print PLT

2723 GstarCAD MY /KW December 7, 2021 [Workflow](#) 0 1350


Users can send PLT files to printer for printing.

Menu: Express tools>Plot Tool>Print PLT

Command Entry : PrintPlt

Operation Steps:

1. Start the command.
2. Select PrintPlt.exe in the dialog box.



3. Double-click the PrintPlt.exe file, then the "Print" dialog box will be displayed, in the dialog box you can select printer or change settings.

4. Click the OK button, the "Open" dialog box will be displayed and you can select the printed file.

Online URL: <https://www.gstarcad.com.my/knowledge/article/print-plt-2723.html>