

3DMESH command

1200 GstarCAD Malaysia June 30, 2021 [3D CAD](#) 0 4157

The 3DMESH command is used to create polygonal mesh in any styles.

Command

3DMESH

Ribbon: 3D > Mesh > 3D Mesh

Menu: Draw > Modeling > Meshes > 3D Mesh

Command Prompts

Enter size of mesh in M direction:

Enter size of mesh in N direction:

Specify location for vertex (0, 0):

Specify location for vertex (0, 1):

Function Description :

The density of mesh controls number of mosaic surface. The mesh is defined by M×N vertexes of rectangles, this is similar to row and column of grid. It is a traditional way to create mesh by 3DMESH command and designed for program operation rather than manual operation.

Relative Glossary :


- **Size of mesh in M direction** : Specify size of mesh in M direction, it is a value between 2 and 256.
- **Size of mesh in N direction** : Specify size of mesh in N direction, it is a value between 2 and

256. The value of $M \times N$ must be equal to the specified vertex number.

- **Location for vertex (0, 0) :** Specify coordinates for each vertex. Users could input two dimension or three dimension coordinates. The location for each vertex is determined by the M and N (M is the subscript of row and N is the subscript of column). Define vertex coordinate beginning with (0, 0) and firstly specify the vertex coordinate with M, and then specify M+1.

The distance of vertex could be any value and directions of M and N are determined by their coordinate locations.

Meshes created by 3DMESH command are open in M and N direction; users could use PEDIT command to close them.



Online URL: <https://www.gstarcad.com.my/knowledge/article/3dmesh-command-1200.html>