

ROTATE3D command

2336 GstarCAD MY /KW August 20, 2021 [CAD Commands](#) 0 879

The **ROTATE3D** command is used to rotate objects around 3D axis.

Command Access:

Ribbon : 3D > 3D Operations > Rotate 3D

Menu : Modify > 3D Operations > Rotate 3D

Command : ROTATE3D

Command Prompts:

UCS current positive angle: ANGDIR=counter clockwise ANGBASE=0 Select object:
Specify first point on axis or define axis by [Object/Last/View/Xaxis/Yaxis/Zaxis/2points]:
Relative Glossary:

Object:

Align the selected object to rotation axis.

Line:

Align the selected object to rotate axis.


Angle:

Rotate the object around the selected line by specified angle.


Reference:

Specify reference angle and new angle.

The difference value between the start angle and endpoint angle is the rotation angle.



Circle : Align the rotation axis to the 3D axis of circle (the rotation axis goes across the circle center and is perpendicular to the circle plane).



Arc : Align the rotation axis to the 3D axis of arc (the rotation axis goes across the arc center and is perpendicular to the arc plane).


2D-polyline segment : Align the rotation axis to polyline. The line in polyline could be seemed as line segment and the arc in polyline could be seemed as arc segment.

Last : Rotate selected object by the previous axis.

View : Align the rotation axis to the observation direction of current viewport that goes through one specified point.

Xaxis, Yaxis, Zaxis : Align the rotation axis to one of the axes(X, Y or Z) that goes through one specified point.

2points : Specify the rotation axis by two points.



Online URL: <https://www.gstarcad.com.my/knowledge/article/rotate3d-command-2336.html>