XLINE command

2450 GstarCAD MY /KW August 25, 2021 <u>CAD Commands</u> 0 1188 The **XLINE** command is used to create infinitely long straight lines.

Command Access:

Ribbon: Home > Draw > XLINE **Menu**: Draw > Construction Line

Command: XLINE

Command Prompts:

Specify a point or [Hor/Ver/Ang/Bisect/Offset]:


Function Description:

Users could create the structure and reference lines by infinitely long straight lines, and this kind of lines could trim.


Relative Glossary:

Point:


Create an xline by two specified points. Those two points determine the position of xline.



Hor: Create a horizontal xline through specified point. This xline is parallel to X axis.



Ver: Create a vertical xline through specified point. This xline is parallel to Y axis.




Ang: Create an xline by specified angle.

Angle of xline:

Specify angle of xline.


Reference:

Specify angle between xline and selected reference. This angle is calculated by anticlockwise direction.



Bisect:

Create an xline through specified vertex and bisecting two lines' intersection angle. This xline is determined by three points.



Offset:

Offset distance : Specify offset distance from selected object.

Through: Create an xline that through specified point and offsetting selected line.

Online URL: https://www.gstarcad.com.my/knowledge/article/xline-command-2450.html